

# FORMA Dune


Villeroy & Boch  
1748



	CM.	UV.	
Piatto piano senza ala	32	6	3300172131
Piatto piano ala curva	29	6	3300172132
Piatto piano senza ala	25	12	3300172133
Ovale	36	6	3300173107
Ovale	26	6	3300173108
Tazza caffè impilabile	12	12	3300172134
Piattino caffè	13	12	3300172135
Tazza the lt.0,22	12	12	3300172136
Piattino the	16	12	3300172137
Cremierina lt.0,15	1	1	3300172138
Zuccheriera lt.0,16	1	1	3300172140
Caffettiera lt.0,33	1	1	3300172141
Theiera lt.0,40	1	1	3300172142
Insalatiera	27	1	3300172143
Coppetta fonda	15	1	3300172144
Coppetta bassa	14	12	3300172145
Coppetta 3 scomparti	1	12	3300172146

Villeroy & Boch  
1748

# FORMA Marchesi



	CM.	UV.	
Piatto piano (int.cm.22)	29	6	3300154664
Piatto piano (int.cm.18)	29	6	3300154663
Piatto piano (int.cm.14,5)	29	6	3300154662
Platto fondo (int.cm.14,5)	29	6	3300177674
Piatto fondo pasta	30	6	3300154667
Piatto quadro 5 scomparti	29	6	3300154671